



**EXTREME OUTDOOR
SPORTS SCIENCE**

XOSS



XOSS G

GPS POSITIONING

- ① **Long press the right button to turn on**
- ② **Short press the left button to start searching for GPS**
( The GPS icon appears and starts to flash)
- ③ **After startup, stay still for a few minutes to acquire GPS signal**
 When the GPS icon stops flashing with BEEP prompt, it indicates the device is ready.
- ④ **Long press the left button to save the workout after ending the ride**
(The Bike Computer restores the initial interface.)

Note: When searching for a GPS signal, please remain static and make sure your device is used at open space and barrier-free area. Moreover, the device only supports outdoor recording.



Left Button

Long Press: End recording

Short Press: Start / Pause / Resume

Right Button

Long Press: Power on / Off

Short Press: Switch data display

Battery Capacity



>75%



>50%



>25%



>5%



<5%

Note: When charging, the battery icon in the upper right corner will change from empty to full. And when there are three bars and it doesn't flash, it means charging is completed.

Connect with XOSS APP

Search XOSS in Google Play/App Store, or scan QR CODE on the right to download XOSS APP.

- ① Turn on XOSS G and make sure the Bluetooth of the phone is on.
- ② Open the XOSS APP, select Devices > Bike Computers > G/G+.

After connecting XOSS G to XOSS APP: click on settings to change Backlight, Key Tone, Auto Pause, Speed Alert, Units, Time Zone, etc.; the workout data will be automatically synced to XOSS APP.

Note: Long press the left button to end recording before connection. The App is designed for Bluetooth 4.0 or later versions.



XOSS APP



QR CODE

Manage the workout


- ① Connect G to XOSS APP.
- ② Click **Storage > Workout**.
- ③ Click **Edit** in the upper right corner to select one or the multiple workouts you want to delete or resync.

Custom Data Layout

- ① Connect G to XOSS APP.
- ② Click **Data Layout**.
 - Firmware version requirement: 1.09 version or later
 - XOSS app version: Android 3,10,2 or later, iOS 3,11,0 or later

Time Zone Setting in XOSS APP

- ① Connect G to XOSS APP.
- ② Click **Settings > User Profile > Time Zone**.
 - It will sync the device with the phone's timezone.



Record 12 Types of Data



- ① **CLOCK** (Clock)
TEMP (Temperature)
SPD (Current Speed)
GRD (Grade)
TIME (Total Time)
DIST (Distance)
- ② **AVG** (Average Speed)
ELE (Elevation)
CAL (Calories)
- ③ **MAX** (Max Speed)
GAIN (Elevation Gain)
ODO (Odometer)

[Metric/Imperial] [Time Zone] Settings



Long press both button to enter into setting interface.



Metric/Imperial Unit Setting
Press the left button: switch units
Long press the right button: next step



Time Zone Setting
Press the left button: switch numbers
Press the right button: switch position
Long press the right button: end setting

Packing List



XOSS G x 1



Cycling Computer Mount x 1



Type-C USB Cable x 1



Protection Rubber Pad x 1




Rubber Band x 2



User Manual x 1

Installation

- 1 Put the rubber pad on the back of the bike stand;
- 2 Use a rubber band to secure the bracket to the handlebar or stem;
- 3 Align the tabs on the back of the device with the grooves on the bike stand, press down slightly, and rotate the device 90 degrees until it locks into place.



Cross tie the base with a rubber band



Install the Cycling Computer

Firmware Upgrade

When there is new firmware available, the XOSS APP will prompt you to update it. It is best for you to keep the latest firmware.

• If you are stuck at dFu during the firmware upgrade, you could try toggling Bluetooth off and back on again in your phone's settings and reconnect the XOSS APP to upgrade it again.

Specification

Name: XOSS G Smart GPS Cycling Computer

Size: 55.6mm x 86.2mm x 18.4mm

Product Weight: 57g

Operating Temperature: -10°C ~ 50°C

Endurance Time: 40 hours

Battery: 600mAh Rechargeable Lithium Ion

Waterproof: IP67

Data Display: 12 Types of Data

After-sales Service & Warranty

It has a one-year free warranty from the date of purchase, please contact your original dealer for warranty service.

The following conditions are not covered by the warranty:

1. The normal aging loss of the battery;
2. Damage and loss of products due to improper installation;
3. Damage caused by abnormal use, such as high temperature and water damage;
4. Damage caused by dismantling yourself or by unauthorized maintenance personnel.

Support

Please access <https://www.xoss.co> or help.xoss.co for more product information.